

Figure 1

(1/9)




Figure 2

(2/9)

Operation of the keyboard type determination
processes in the case of scan code set 1





Figure 4

(4/9)

Type F

210




101050 20522050

Figure 5

(5/9)

Type G

210



09072507 100000

Figure 6

(6/9)

601

Password	Item Specific Help
On-Screen Keyboard Type [Type-E] Power-On Password [Disabled] Supervisor Password [Enabled] Hard Disk Password [Disabled]	

Figure 7

601

701

Password	Item Specific Help
On-Screen Keyboard Type [Type-E] Power-On Password [Disabled] Supervisor Password [Enabled] Hard Disk Password [Disabled]	


On-Screen Keyboard Type

Press 'Z' key

Current Selection [Type-E]

Figure 8


(7/9)



801

Figure 9

(8/9)



106.

[illegible]

Figure 10

(9/9)

1001

